



GAS BBQ INSTRUCTIONS



This catering BBQ is perfect for any event, private or commercial. It has a large cooking bed and each end is independently temperature controlled.

Please follow the instructions below to use this unit safely and accordingly.

SAFETY:

- The BBQ is for outdoor use only.
- Parts of this unit will become very hot when in use; therefore, suitable precautions must be taken to avoid accidental burns.
- Do not move the appliance whilst it is alight or in the hot condition.
- Turn off the Gas supply at the cylinder after use.

SETTING UP:

- Hold the barbeque on its side and release the folded legs from their retaining clips at either end of the BBQ. Swing the legs out completely and rotate the inner struts so they can be pushed firmly into the same retaining clips. Stand the BBQ upright on a firm and level surface.
- Do not use the space underneath the BBQ or near the fat drainer container.
- When required, use an empty ring-pull drinks can as a fat drain container. A stainless-steel clip emerges from each drain hole, which can be found within the area of the chromed hoop at either end of the BBQ. Thread the clip through the hole in the can. (Use gloves when removing the can which may be very hot.)
- The BBQ is designed to be free standing, ensure it is placed on a firm and level surface.
- When selecting the location, ensure the BBQ is not near or under combustible materials or in an excessively windy environment.
- Ensure that the gas cylinder is not placed in contact or underneath the BBQ, and that the hose is neither strained nor stretched.
- Use the correct size spanner to tighten the regulator to the propane cylinder in ANTI-CLOCKWISE directions when viewed from the hose connection.

LIGHTING THE BBQ:

- Turn BOTH control valves OFF, by turning them clockwise to a firm stop.
- Turn the supply from the cylinder ON by turning the cylinder valve anti-clockwise.

- A leak check should be carried out at this point, use a soapy water solution around all gas connections at both ends of the BBQ and along the hose. Turn the gas OFF at the propane cylinder if the solution bubbles to indicate a leak, call a qualified LGP gas engineer if a leak is detected.
- If no leaks are indicated, turn the gas ON by turning the cylinder valve anti-clockwise.
- Insert a match into the brass lighting hole (located centrally underneath) and turn ON the desired side of the BBQ by turning the switch anti-clockwise at that end from 6 o'clock to 3 o'clock position whilst pressing and holding the knob for approx 1 minute then release and turn to 12 o'clock position for full power.
- If the burner does not light immediately, switch off the gas cylinder and wait 5 minutes before trying again.
- To switch on the other end, repeat the steps above with the opposite end (same brass lighting hole)

PACKING DOWN:

When you've finished with the BBQ please follow instructions below:

- Turn off the gas supply at the cylinder valve in a clockwise direction to a firm 'stop'.
- Turn the control valves at both ends of the BBQ to the OFF position by turning them also clockwise to a firm 'stop'.
- Detach the regulator from the gas cylinder if cooking is finished by unscrewing clockwise when viewed from the hose connection and replace the protective plastic plug into the cylinder outlet.
- Wait for the BBQ to cool before moving.

Please note this unit is included in our 'Free Return Dirty' Service, however, we do expect that all foodstuffs have been removed and a light wipe over of any spillages.

In the event of any issues please call us on: 01949 844568 or email us at hello@inspireeventhire.com