



PROPANE GAS BOTTLE INSTRUCTIONS



All our propane gas bottles (11kg) are compatible with all our gas-powered items.

SAFETY:

- Always treat the cylinder with care to avoid damage and danger.
- Keep the cylinder in an upright position at all times.
- Be careful when lifting the cylinders. Full gas cylinders weigh twice as much as that displayed on them.
- Check the appliance is securely and safely fastened to the gas source before using.
- When using the gas bottle make sure it is in a well-ventilated area.
- Ensure the appliance your using is on a level, non-combustible surface.
- The appliance must never be left unattended whilst it is on and in use.
- Never use the cylinder below ground level or in an underground environment. Gas is lighter than air and can asphyxiate in these situations.
- Do not attempt to modify or improvise any of the equipment.
- Do not alter the regulator level on the cylinder.
- Do not expose the cylinder to naked flames.

CONNECTING:

To start using the gas bottle follow the instructions:



- Check the valve hand wheel is OFF by turning CLOCKWISE.
- Remove the protective plug (if there is one) and leave hanging for after use.
- Inspect the bullnose connection of the regulator for damage before connecting.
- Fit the connecting nut to the regulator using the correct sized spanner. The connection should be tight and secure.
- Ensure all appliances are turned off.
- When gas is required, turn the valve hand wheel, ANTI-CLOCKWISE to ON (releasing the gas to the appliance).

DISCONNECTING:



Once you have finished using the gas bottle, follow the instructions below:

- Ensure the appliance connected to the gas bottle is switched off.
- Turn the hand wheel valve on the cylinder to OFF in a CLOCKWISE direction.
- Do not remove the regulator or connecting nut with the cylinder valve open.

In the event of any issues please call us on: 01949 844568 or email us at hello@inspireeventhire.com